



- |   |                             |   |                         |
|---|-----------------------------|---|-------------------------|
| Ⓧ | Montageanleitung            | Ⓧ | Assembly instructions   |
| Ⓧ | Notice de montage           | Ⓧ | Istruzioni di montaggio |
| Ⓧ | Handleiding voor de montage | Ⓧ | Instrukcja montażu      |
| Ⓧ | Montážní návod              | Ⓧ | Návod na montáž         |
| Ⓧ | Szerelési utmutato          | Ⓧ | Instrucțiuni de montaj  |
| Ⓧ | Montaj talimatı             | Ⓧ | Инструкция по монтажу   |

Ausgabe:20200704




0  
10  
20  
30  
40  
50  
60  
70  
80  
90  
100  
110  
120  
130  
140  
150  
160  
170  
180  
190  
200




Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба		
Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Isim • Название	SARINA	
Nr. • No. • N° • Номер • Č • Sz	7290 5936	
Typ • Type • Tip • Típus • Tipo Тип	YS-DR6376	




<b>A</b>	M6X16MM X21	<b>B</b>	X1	<b>C</b>	X4
----------	----------------	----------	----	----------	----






1

<b>A</b> M6X16MM  X16	<b>B</b>  X1	<b>C</b>  X4
---	---	---



2

A	M6X16MM	B		X1
				X5



3

